Printer Compatibility HP

AGFAPHOTO

HP OEM-Nr.	HP15	HP45	HP78	HP56	HP57	HP21	HP22	HP27	HP28	HP336	HP337	HP338	HP339	HP342	HP343	HP344	HP348	HP350	HP351	HP363bk	HP363c	HP363m	HP363y	HP363lp	HP363lm
AgfaPhoto Nr.	APHP15B	APHP45B	APHP78C	APHP56B	APHP57C	APHP21B	APHP22C	APHP27B	APHP28C	APHP336B	APHP337B	APHP338B	APHP339B	APHP342C	APHP343C	APHP344C	APHP348C	APHP350B	APHP351C	APHP363B	APHP363C	APHP363M	APHP363Y	APHP363LC	APHP363LM
Printer model																									
Colour Copier 110, 120, 140, 145, 150, 155, 160, 170		■																							
Colour Copier 180, 190		■	■																						
Colour Copier 210/lx, 260, 270		■																							
Colour Copier 280, 290		■	■																						
Color Copier 310	■		■																						
Deskjet 450cbi/ci/wbt				■	■																				
Designjet 700, 750c/plus, 755cm/plus		■																							
Deskjet 460c/cb/wbt												■			■	■	■								
Deskjet 710c, 712c, 720c, 722c		■																							
Deskjet 810c, 812c, 815c, 816c	■																								
Deskjet 820cse/cxi		■																							
Deskjet 825c/cvr	■																								
Deskjet 830c, 832c		■																							
Deskjet 840c, 841c, 842c, 843c, 845c/cvr	■																								
Deskjet 850c, 855c/cse, 870cse/cxi, 880c, 882c		■																							
Deskjet 890cse/cxi, 895cse/cxi		■																							
Deskjet 916c, 920c/cvr	■		■																						
Deskjet 930c/cm, 932c, 935c		■	■																						
Deskjet 940c/cvr	■		■																						
Deskjet 950c, 952c		■	■																						
Deskjet 955c	■																								
Deskjet 959c, 960c, 970cse/cxi, 980cxi, 990cse/cxi, 995c/ck		■	■																						
Deskjet 1000cse/cxi, 1100c, 1120c, 1120cse, 1120cxi, 1125c, 1180c		■																							
Deskjet 1180c		■	■																						
Deskjet 1220c, 1220C/PS, 1280		■	■																						
Deskjet 1600c/cm		■																							
Deskjet 3320, 3325, 3420, 3425, 3450								■	■																
Deskjet 3520, 3535, 3550								■	■																
Deskjet 3620, 3645, 3647, 3650, 3745								■	■																
Deskjet 3810, 3816	■																								
Deskjet 3820, 3822	■		■																						
Deskjet 3845								■	■																
Deskjet 3910, 3915, 3918, 3920, 3930, 3938, 3940						■	■																		
Deskjet D4260, D4360																			■						
Deskjet 5145, 5150/c, 5151, 5160				■	■																				
Deskjet 5360																			■						
Deskjet 5420, 5432, 5440, 5442, 5443										■					■		■								
Deskjet 5550, 5551, 5552				■	■																				
Deskjet 5650, 5652, 5655				■	■			■	■																
Deskjet 5740, 5743, 5745, 5748												■	■		■	■	■								
Deskjet 5850				■	■			■	■																
Deskjet 5940										■		■			■	■	■								
Deskjet 6120		■																							
Deskjet 6122, 6127		■	■																						
Deskjet 6520, 6540/d, 6543, 6548, 6620, 6830v, 6840, 6843, 6848												■	■		■	■	■								
Deskjet 6940, 6980										■		■			■	■	■								
Deskjet 9300		■	■																						
Deskjet 9600, 9650, 9670, 9680/gp				■	■																				
Deskjet 9800/d												■	■		■	■	■								
Deskjet D1320, D1330, D1360, D1368						■	■																		
Deskjet D1420, D1430, D1445, D1455, D1460, D1470						■	■																		
Deskjet D2360, D2430, D2460						■	■																		
Deskjet D4145, D4155, D4160, D4163, D4168										■					■	■	■								
Deskjet AIO F310, F325, F335, F340, F350						■	■																		
Deskjet AIO F370, F375, F378, F380, F385, F388, F390, F394						■	■																		
Deskjet AIO F2100, F2110, F2120, F2128, F2149, F2180, F2185, F2187, F2188						■	■																		
Deskjet AIO F4135, F4140, F4150						■	■																		
Deskjet AIO F4172, F4175, F4180, F4185, F4188, F4190, F4195						■	■																		
Digital Copier 410				■	■																				
Officejet g55, g85, g95		■	■																						
Officejet k60, k80		■	■																						
Officejet r40, r45, r60, r65, r80		■																							
Officejet t45, t65		■																							
Officejet v30, v40, v40xi, v45	■		■																						
Officejet 4105, 4110, 4115				■	■				■																
Officejet 4211, 4212, 4215, 4219				■	■			■	■																
Officejet 4251, 4252, 4255, 4259				■	■			■	■																
Officejet 4311, 4312, 4314, 4315, 4317, 4319, 4352, 4353, 4355, 4357, 4359								■																	
Officejet 5105, 5110	■		■																						
Officejet 5505, 5508, 5510, 5515				■	■																				
Officejet 5605				■	■																				
Officejet 5607								■																	

AgfaPhoto is used under license of Agfa-Gevaert NV & Co. KG or Agfa-Gevaert NV. Neither Agfa-Gevaert NV & Co KG nor Agfa-Gevaert NV manufacture this product or provide any product warranty or support. For service, support and warranty information, contact the distributor or manufacturer. AgfaPhoto Holding GmbH, www.agfaphoto.com **Distributed by swiss ink & paper ag, Switzerland, www.swissinkpaper.ch**

Printer Compatibility HP

AGFAPHOTO

HP OEM-Nr.	HP15	HP45	HP78	HP56	HP57	HP21	HP22	HP27	HP28	HP336	HP337	HP338	HP339	HP342	HP343	HP344	HP348	HP350	HP351	HP363bk	HP363c	HP363m	HP363y	HP363lc	HP363lm
AgfaPhoto Nr.	APHP15B	APHP45B	APHP78C	APHP56B	APHP57C	APHP21B	APHP22C	APHP27B	APHP28C	APHP336B	APHP337B	APHP338B	APHP339B	APHP342C	APHP343C	APHP344C	APHP348C	APHP350B	APHP351C	APHP363B	APHP363C	APHP363M	APHP363Y	APHP363LC	APHP363LM
Officejet 5608, 5609, 5610, 5615				■	■			■																	
Officejet 6105, 6110								■	■																
Officejet 6111				■	■																				
Officejet 6205, 6210, 6215												■			■	■	■								
Officejet 6310, 6313, 6315										■	■		■	■	■		■								
Officejet 7210, 7310, 7410												■	■		■	■	■								
Officejet AIO 4311 - 4315, 4317, 4319, 4352, 4353, 4355, 4357, 4359						■	■																		
Officejet AIO 5605, 5607, 5608, 5609, 5610, 5615							■																		
Officejet AIO J3608, J3640, J3650, J3680						■	■																		
Officejet H470										■	■				■	■	■								
Officejet J5730, J5780, J5785, J5790																	■	■	■						
Officejet J6410, J6415, J6424, J6450, J6480																	■	■	■						
Officejet Pro 1150c, 1170c, 1175c		■																							
Officejet Pro K7100, K7103, K7108										■	■	■			■	■	■								
Photosmart 325, 335, 375, 385, 422, 425, 428, 475															■	■									
Photosmart 1000, 1100, 1115		■	■																						
Photosmart 1215, 1218		■	■																						
Photosmart 1315		■	■																						
Photosmart 2570, 2575										■	■		■	■	■	■	■								
Photosmart 2610, 2710												■	■		■	■	■								
Photosmart 3200 Series, 3300 Series																				■	■	■	■	■	■
Photosmart 7150, 7260, 7345, 7350, 7450, 7459, 7550				■	■																				
Photosmart 7655, 7660, 7755, 7760, 7762, 7960/gp				■	■																				
Photosmart 7850										■		■		■	■		■								
Photosmart 8050											■	■		■	■	■	■								
Photosmart 8150												■		■	■	■	■								
Photosmart 8250																				■	■	■	■	■	■
Photosmart 8450/gp, 8750/gp												■	■		■	■	■								
Photosmart C3170, C3180, C3190										■		■		■	■		■								
Photosmart C4160, C4180, C4190											■			■	■		■								
Photosmart C4270																		■	■						
Photosmart C4272, C4280																	■	■	■						
Photosmart C4340																		■	■						
Photosmart C4380																	■	■	■						
Photosmart C4424, C4472																		■	■						
Photosmart C4480																	■								
Photosmart C4485																		■	■						
Photosmart C4524, C4580, C4599																		■	■						
Photosmart C 5100 Series																				■	■	■	■	■	■
Photosmart C 6100 Series																				■	■	■	■	■	■
Photosmart C 5280																	■	■	■						
Photosmart C 6200 Series, C 7100 Series, C 7200 Series																				■	■	■	■	■	■
Photosmart C 8100 Serie																				■	■	■	■	■	■
Photosmart D 5160										■		■		■	■	■	■								
Photosmart D 5360																	■								
Photosmart D 6100 Series																				■	■	■	■	■	■
Photosmart D 7100 Series, D 7300 Series																				■	■	■	■	■	■
Photosmart P1100 Series		■	■																						
Photosmart Pro B8350												■	■		■	■	■								
PSC 500	■																								
PSC 750	■		■																						
PSC 750xi	■																								
PSC 950	■		■																						
PSC 950xi	■																								
PSC 1100				■	■																				
PSC 1110				■	■			■																	
PSC 1200								■																	
PSC 1205				■	■			■																	
PSC 1210, 1213, 1215				■	■			■	■																
PSC 1216								■	■																
PSC 1217, 1219				■	■			■	■																
PSC 1310, 1311, 1312, 1315, 1317, 1318				■	■			■	■																
PSC 1340, 1345, 1350, 1355				■	■																				
PSC 1401, 1402, 1403, 1406, 1408, 1410, 1415, 1417						■	■																		
PSC 1507, 1510/s, 1513/s										■		■		■	■		■								
PSC 1600, 1610, 1613										■		■			■	■	■								
PSC 2105, 2108, 2110, 2115, 2170, 2171, 2175, 2179				■	■																				
PSC 2210, 2405, 2410, 2420, 2510				■	■																				
PSC 2350, 2353, 2355/p												■		■	■	■									
Fax 1220		■	■																						
Fax 1230	■		■																						
Fax 1240				■	■			■	■																
Fax 1250						■	■	■																	

AgfaPhoto is used under license of Agfa-Gevaert NV & Co. KG or Agfa-Gevaert NV. Neither Agfa-Gevaert NV & Co KG nor Agfa-Gevaert NV manufacture this product or provide any product warranty or support. For service, support and warranty information, contact the distributor or manufacturer. AgfaPhoto Holding GmbH, www.agfaphoto.com **Distributed by swiss ink & paper ag, Switzerland, www.swissinkpaper.ch**